

QUICK INSTALLATION GUIDE



ARGB

AURA GC8

Mid-Tower PC Case


TABLE OF CONTENTS

1	Specifications
2	Exploded View & Parts
3	Accessory
4	Side Panel Removal
5	Motherboard Installation
6	PSU Installation
7	3.5" & 2.5" HDD Installation
8	Air Cooling Compatibility
9	Radiator Compatibility
10	I/O Ports
11	I/O Connectors

SPECIFICATIONS

SERIES	AURA Series
Product Name	AURA GC8 ARGB
Case Type	MID Tower
Dimension (L x W x H)	350 x 188 x 430 mm 13.9 x 7.4 x 16.9 inch
Chassis Dimension (L x W x H)	310 x 188 x 420 mm 12.2 x 7.4 x 16.5 inch
Motherboard Support	ATX, Micro-ATX, Mini-ITX
Expansion Slots	7
Material	SPCC, ABS, Tempered glass
Window	Left
Radiator Support	Rear: 120 mm
Fan Support	Top: 2 x 120mm Front: 3 x 120mm Rear: 1 x 120mm
Pre-installed Fans	Rear: 1 x 120mm ARGB Fan
Pre-installed Control BOX	NO
Motherboard Sync	NO
Drive Bays	2 x 3.5" or 1 x 2.5"+1 x 3.5"(HDD Cage) 1 x 2.5"
Clearance	CPU cooler height limitation: 155mm VGA length limitation: 300mm PSU length limitation: 160mm
I/O Port	USB 3.0 x1, USB 2.0 x2, HD Audio x1, LED Switch x1

EXPLODED VIEW & PARTS



PARTS


1	Chassis Body	6	Front Panel
2	Tempered Glass Side Panel	7	Right Side Panel
3	Screw	8	IO Port
4	Rubber Foot	9	Top Dust Filter
5	HDD Cage	10	120mm ARGB Fan

ACCESSORY


FIGURE	PARTS NAME	QTY	USED FOR
 	Stand-off 4.75 x 9.5 x 6.5mm	3	Motherboard
 	Screw #6 x 6 mm	6	PSU
 	Screw #6 x 5 mm	9	HDD
 	Screw M3 x 5 mm	18	2.5" HDD/Motherboard/ODD
	CableTie	5	Cable Management

SIDE PANEL REMOVAL

1



2



English

Remove the side panel

Español

Retire el panel lateral

Deutsch

Seitenblende entfernen

Polski

Usuń panel boczny

Français

Retirez le panneau latéral

Svensk

Ta bort sidopanelen

Italiano

Rimuovere il pannello laterale

Português

Remova o painel lateral

Русский

Снимите боковую панель

Türk dili

Yan paneli çıkarın

日本語

サイドパネルを取り外します

한국어

사이드 패널 제거


ภาษาไทย

ถอดแผงด้านข้าง

العَرَبِيَّة

فك اللوحة الجانبية

MOTHERBOARD INSTALLATION



English

Lay down the chassis
Install the motherboard in proper location
and secure it with screws

Español

Tumbe el chasis
Instale la placa base en la posición adecuada
y fíjela con los tornillos

Deutsch

Gehäuse flach hinlegen
Motherboard an der richtigen Stelle installieren
und mit Schrauben sichern

Polski

Położ obudowę
Zamontuj płytę główną we właściwym miejscu
I przymocuj za pomocą śrubek

Français

Déposez le châssis
Installez la carte mère dans un emplacement
approprié et fixez-la avec des vis

Svensk

Lägg ner chassiet
Sätt i moderkortet på rätt plats och fäst med
skruvar

Italiano

Poggiare il telaio
Installare la scheda madre nella posizione
corretta e fissarla con viti

Português

Deite o chassi
Instale a placa-mãe no local correto e
prenda-a com parafusos

Русский

Снимите подставку
Установите системную плату в нужном
месте и закрепите винтами

Türk dili

Kasayı yere yatırın
Ana kartı uygun konuma kurun ve vidalarla
sabitleyin

日本語

シャーシーを置きます。
マザーボードを適切な位置に取り付け、
ねじで固定します。

한국어

새시 깔기
마더보드를 올바른 위치에 놓은 뒤
볼트로 고정합니다


ภาษาไทย

วางตัวเครื่องลง
ติดตั้งมาเธอร์บอร์ดในตำแหน่งที่ถูกต้องแล้ว
ยึดด้วยสกรู

العَرَبِيَّة

ضع الهيكل (الشاسيه) على سطح.
رُكِّب اللوحة الأم في المكان السليم وأحكم تثبيتها بالمسامير.

PSU INSTALLATION



English

Place the PSU in proper location

Português

Coloque a PSU no local adequado

Español

Coloque la PSU en la posición adecuada

Русский

Поместите блок питания в нужное место

Deutsch

Netzteil an der richtigen Stelle platzieren

Türk dili

PSU'yu uygun konuma yerleştirin

Polski

Umieścić zasilacz we właściwym miejscu

日本語

電源ユニットを適切な位置に置きます。

Français

Positionnez le bloc d'alimentation électrique dans un emplacement approprié

한국어

PSU를 올바른 위치에 놓습니다

Svensk

Placera PSU:n på rätt plats

ภาษาไทย

วาง PSU ในตำแหน่งที่ถูกต้อง

Italiano

Collocare il PSU in posizione corretta


العربية

ضع وحدة إمداد الطاقة في المكان السليم.


3.5" & 2.5" HDD INSTALLATION

3.5" HDD



A



B



2.5" SSD



English

A. 3.5" HDD

Align the HDD into the mounting holes and screw in.

B. 2.5" SSD

Align the SSD into the mounting holes and screw in.

Español

A. HDD de 3,5"

Alinee el HDD en los orificios de montaje y apriete los tornillos.

B. SSD de 2,5"

Alinee el SSD en los orificios de montaje y apriete los tornillos.

Deutsch

A. 3,5-ZOLL-FESTPLATTE

Festplatte in den Montagelöchern ausrichten und einschrauben.

B. 2,5-ZOLL-SSD

SSD in den Montagelöchern ausrichten und einschrauben.

Polski

A. DYSK TWARDY HDD 3,5"

Dopasuj dysk twardy HDD do otworów montażowych i przykręć go.

B. Dysk twardy SSD 2,5"

Dopasuj dysk twardy SSD do otworów montażowych i przykręć go.

Français

A. Disque dur 3,5"

Alignez le disque dur dans les trous de montage et vissez-le.

B. SSD 2,5"

Alignez le SSD dans les trous de montage et vissez-le.

Svensk

A. 3,5" HDD

Sätt i HDD:n i monteringshålen och skruva fast.

B. 2,5" SSD

Sätt i SSD:n i monteringshålen och skruva fast.

Italiano

A. HDD da 3,5"

Allineare l'HDD nei fori di montaggio e avvitarlo.

B. SSD da 2,5"

Allineare l'SSD nei fori di montaggio e avvitarlo.

Português

A. HDD 3.5"

Alinhe o HDD nos orifícios de montagem e aperte-o.

B. HDD 2.5"

Alinhe o SSD nos orifícios de montagem e aperte-o.

Русский

A. Жесткий диск 3,5 дюйма

Установите жесткий диск в монтажные отверстия и закрепите винтами.

Б. Твердотельный накопитель 2,5 дюйма

Вставьте твердотельный накопитель в монтажные отверстия и закрепите винтами.

Türk dili

A. 3,5" SABİT DİSK

Sabit disk bağlantı düzeneği delikleriyle hizalayın ve vidalayın.

B. 2,5" KATI HÂL DİSKİ

Katı hâl diskini bağlantı düzeneği delikleriyle hizalayın ve vidalayın.

日本語

A.3.5インチHDD

HDDを取り付け穴にあて、回し入れます。

B.2.5インチHDD

SSDを取り付け穴にあて、回し入れます。

한국어

A. 3.5" HDD

HDD를 마운팅 홀에 정렬한 뒤 볼트로 고정합니다.

B. 2.5" HDD

SSD를 마운팅 홀에 정렬한 뒤 볼트로 고정합니다.

ภาษาไทย

A. ฮาร์ดดิสก์ไดรฟ์ขนาด 3.5 นิ้ว

จัดเรียงฮาร์ดดิสก์ไดรฟ์ลงในช่องสำหรับประกอบแล้วขันสกรูยึดให้แน่น

B. โซลิดสเตตไดรฟ์ขนาด 2.5

จัดเรียงโซลิดสเตตไดรฟ์ลงในช่องสำหรับประกอบแล้วขันสกรูยึดให้แน่น

العربية


أ- محرك الأقراص الثابتة 3.5 بوصة

قم بمحاذاة المحرك في فتحات التثبيت وثبته.

ب- محرك الأقراص ذو الحالة الثابتة 2.5 بوصة

قم بمحاذاة المحرك في فتحات التثبيت وثبته.

AIR COOLING COMPATIBILITY



English

Top 120 mm x 2
Front 120 mm x 3
Rear 120 mm x 1

Svensk

Ovansida 120 mm x 2
Framsida 120 mm x 3
Baksida 120 mm x 1

日本語

上部 120 mm x 2
前部 120 mm x 3
後部 120 mm x 1

Español

Superior 120 mm x 2
Frontal 120 mm x 3
Trasero 120 mm x 1

Italiano

Parte superiore 120 mm x 2
Parte anteriore 120 mm x 3
Parte posteriore 120 mm x 1

한국어

상단 120 mm x 2
전면 120 mm x 3
후면 120 mm x 1

Deutsch

Oben 120 mm x 2
Vorne 120 mm x 3
Hinten 120 mm x 1

Português

Superior 120 mm x 2
Frente 120 mm x 3
Traseira 120 mm x 1

ภาษาไทย

ด้านบน 120 มม. x 2
ด้านหน้า 120 มม. x 3
ด้านหลัง 120 มม. x 1

Polski

Góra 120 mm x 2
Przód 120 mm x 3
Tył 120 mm x 1

Русский

Верхний 120 мм, 2 шт.
Передний 120 мм, 3 шт.
Задний 120 мм, 1 шт.

العَرَبِيَّة

علوي 120 مم x 2
أمامي 120 مم x 3
خلفي 120 مم x 1


Français

Haut 120 mm x 2
Avant 120 mm x 3
Arrière 120 mm x 1

Türk dili

Üst 2 tane 120 mm
Ön 3 tane 120 mm
Arka 1 adet 120 mm

RADIATOR COMPATIBILITY



English

Rear 120 mm

Svensk

Baksida 120 mm

日本語

後部 120 mm

Español

Trasero 120 mm

Italiano

Parte posteriore 120 mm

한국어

후면 120mm

Deutsch

Hinten 120 mm

Português

Traseira 120 mm

ภาษาไทย

ด้านหลัง 120 มม.

Polski

Tył 120 mm

Русский

Задний 120 мм

العَرَبِيَّة

خلفي 120مم


Français

Arrière 120 mm

Türk dili

Arka 120 mm


I/O PORTS



1	Power Button	5	Microphone
2	LED Switch	6	USB 2.0
3	USB 2.0	7	USB 3.0
4	Headphone		

② Sync With Motherboard : Press and Hold the Fan LED Control Button for 3 Seconds.

I/O CONNECTORS



English

See your motherboard's manual for front panel header locations and pin-outs.

Português

Veja o manual da sua placa-mãe para localizar os locais e os compartimentos do painel frontal.

Español

Consulte en el manual de la placa base las ubicaciones de los cabezales del panel frontal y las salidas de conectores.

Русский

Схема расположения колодок передней панели и выводов представлена в руководстве к системной плате.

Deutsch

Positionen und Pinbelegungen der Stiftheisten an der Frontblende finden Sie in der Motherboard-Anleitung.

Türk dili

Ön panel bağlantı konumları ve Pi çıkışları için ana kartınızın kılavuzuna bakın.

Polski

Zapoznaj się z instrukcją do płyty głównej w celu uzyskania informacji o położeniu gniazda panelu przedniego i pinów.

日本語

フロントパネルヘッダーの位置と操作はマザーボードマニュアルを参照

Français

Consultez le manuel de votre carte mère pour les emplacements des embases du panneau avant et les sorties pi.

한국어

프론트 패널 헤더 위치와 pi 아웃은 마더보드의 매뉴얼을 참조하십시오.

Svensk

Se bruksanvisningen för moderkortet för huvud och pi-utgångar på framsidan.

ภาษาไทย

อ่านคู่มือมาเธอร์บอร์ดของคุณเพื่อรับทราบตำแหน่งส่วนหัวแผงด้านหน้าและ Pi-out

Italiano

Vedere il manuale della scheda madre per le posizioni e le piedinature del connettore del pannello anteriore.

العَرَبِيَّة

راجع دليل اللوحة الأم لتحديد مواضع رأس اللوحة والدبابيس.

